

Active Wave 250™		DMX Traits
Channel	Value	Function
1	0 - 255	PAN
2	0 - 255	TILT
3 ↓	0 - 127	<u>COLOR</u>
	0 - 9	WHITE
	10 - 20	GREEN
	21 - 31	RED
	32 - 41	CYAN
	42 - 52	LIGHT GREEN
	53 - 63	MAGENTA
	64 - 73	LIGHT BLUE
	74 - 84	YELLOW
	85 - 95	GREEN
	96 - 105	PINK
	106 - 116	BLUE
	117 - 127	ORANGE
	128 - 190	MIX COLOR EFFECT
	191 - 220	BACKWARDS RAINBOW EFFECT FAST → SLOW
	221 - 222	STOP
	223 - 252	FORWARD RAINBOW EFFECT SLOW → FAST
253 - 255	SOUND ACTIVE	
4 ↓	0 - 15	<u>GOBO</u> SPOT
	16 - 31	GOBO 1
	32 - 47	GOBO 2
	48 - 63	GOBO 3
	64 - 79	GOBO 4
	80 - 95	GOBO 5
	96 - 111	GOBO 6

Active Wave 250™		DMX Traits
Channel	Value	Function
4 ↓	112 - 127	GOBO 7
	128 - 132	OPEN
	133 - 144	GOBO 1 SHAKE
	145 - 156	GOBO 2 SHAKE
	157 - 168	GOBO 3 SHAKE
	169 - 180	GOBO 4 SHAKE
	181 - 192	GOBO 5 SHAKE
	193 - 210	GOBO 6 SHAKE
	211 - 217	GOBO 7 SHAKE
	218 - 219	OPEN
	220 - 249	GOBO WHEEL SCROLL
250 - 255	SOUND ACTIVE SLOW → FAST	
5 ↓	0 - 63	<u>SHUTTER</u>
	64 - 95	DIMMER 0 - 100%
	96 - 100	STROBE
	101 - 127	SLOW → FAST
	128 - 159	RESET
	160 - 191	OPEN
	192 - 223	SOUND ACTIVE
	224 - 255	PULSE EFFECT 1
		PULSE EFFECT 2
		OPEN
6 ↓	0 - 127	<u>GOBO ROTATION</u>
	128 - 189	GOBO INDEXING
	190 - 193	FORWARD GOBO ROTATION
	194 - 255	FAST → SLOW
		STOP
	BACKWARDS GOBO ROTATION	
	SLOW → FAST	