

## **Firmware update for Elation 4Cast Bridge**

1. Connect your 4Cast Bridge to your Windows PC with a USB cable.
2. Put the bridge into bootloader mode by holding down the “enter” button on power-up. The display will show “Bootloader Mode”.
3. After extracting the zipped folder on your PC, run the bootloader application "Elation\_4Cast\_Bridge\_USB\_Bootloader" directly from the unzipped folder.
4. From the bootloader application, select and load the firmware file (4Cast Bridge xxx.cyacd) that's included in the folder.
5. Wait until the bootloader application shows "connected".
6. Click the "program" button on the bootloader application and wait until finished programming.
7. The bridge will restart after the program has loaded.